


EPSON PRINTER
DRIVER

To Printer (Centronix Type)



* IC 30, 34, 35, 36
must be 74HC...
to drive printer cable.

* all H → no INTREQ - all LIMS as shown!

PDP 8e I/F - CIRCUIT DIAGRAM

Rev. 0 6. Feb. 1991 *
† 9. Juli 1990

FIG. 1.